

www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209

Before You Begin

Read this entire manual.

Before starting the installation, verify the job site dimensions and the dimensions of the delivered materials against the PFlow Industries, Inc. General Arrangement (GA) drawing. Review and verify the enclosure positions and attachment fit-up to the gate post enclosure angle. If the site conditions do not match the GA drawing, please consult the PFlow Industries, Inc. Customer Support Department.



A DANGER

Falling gate hazard! The installation of this equipment requires a qualified installer with extensive knowledge and experience on how to rig and erect structural steel. Make sure to properly support, tie off, or temporarily brace the gate posts, gate panels, and gate assembly during installation. Do not depend on the gate post feet to support the gate posts while the gate is being positioned or assembled. Final bracing of the gate assembly must be to the Vertical Reciprocating Conveyor (VRC) or building structure. The use of structural angle is recommended.



Falling Hazard! The gate panel safety latch may not be operational while the gate is being installed. If you must leave a gate or gate panel unattended, put up barriers and signs warning personnel to stay clear.

ACAUTION



Lifting hazard! Components and accessories are heavy. To prevent serious personal injury, use the appropriate lifting apparatus, tie offs, or help when moving, lifting or assembling the components or accessories.

NOTICE

A qualified person is defined as a person who, by possession of a recognized degree or certificate of professional standing, or by extensive knowledge, training, and experience, has successfully demonstrated his/her ability to solve problems relating to the subject matter and work.

Identify Components

Gate components, posts, panels, and header assembly have color coded tags. Each gate tag is a different color.

Level	Tag Color
1st (bottom)	Green
2nd	Yellow
3rd	Red
4th	Blue
Other	Cream

The preferred method of installing a gate is to pre-assemble the full gate assembly on the floor, secure the pieces, and then stand it up. If for some reason pre-assembly is not possible, use these instructions as a general guide for the assembling, positioning, and securing of the gates.

Gate Installation Motorized Single Vertical Acting (SVA) Gate



MATERIAL HANDLING SOLUTIONS

www.pflow.com P 414 352 9000 F 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209

Establish Placement	NOTE	It is often possible to assemble the gate on the ground. However, it may not be possible to erect the fully assembled gate. Horizontal assembly and vertical assembly methods are included in this manual. Both methods require additional support and temporary bracing during assembly.	3 1 2 1. Conter ol Carnigo 2. Chalk Line (Cernier)
		1. Measure the outside edge to the outside edge of the carriage to locate the center line. Mark the center line with a pencil on the top of the carriage deck. See Figure 1.	3 Chaik Line (Parallel) 15660-0000-S.SMC 1911 1160 Establish Center Line Figure 1
		 Position a carpenter square on the edge of the carriage to extend the center line onto the floor 10" (254mm) away from the carriage. See Figure 1. 	
		3. Mark a chalk line on the floor to ensure the center of the gate is on the center line of the carriage. See Figure 1.	
	NOTE	The ideal position of the gate panel is a maximum of 6" (152mm) from the inside of the gate panel to the front edge of the carriage. Local codes may have specific requirements concerning this distance.	Overall Gate Width
		4. When the measurement from the back side of the gate panel to the carriage has been determined, snap a chalk line to identify the position of the gate panel parallel to the carriage. See Figure 1.	Establish Gate Width Figure 2
		5. Reference the PFlow Industries, Inc. General Arrangement (GA) drawing to determine the overall gate width.	Maximum 6"(152mm) ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓
		6. Measure the overall gate width and mark the final position for the gate posts. See Figure 2.	1. Parallel Chalk Line 2. Center of Gate Panel Opening Hereits Alignment Figure 3




www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209

Prepare the Chains in the Gate Posts


For shipping purposes, the single vertical acting gate panel counterweight is secured with a shipping screw located toward the bottom of the gate post assembly.

To prevent the chain from falling down into the gate post:

- 1. Remove shipping screw located toward the bottom of the gate post assembly. See Figure 4.
- 2. Pull the counterweight chain forward until the counterweight is moved forward about 2' (610mm).
- 3. Make sure the counterweight is above the shipping screw and replace the shipping screw. See Figure 5.
- 4. Tie one end of a string to the counterweight chain about 3 links back.
- 5. Tie the other end of the string to the base plate of the gate post assembly.
- 6. Carefully handle the gate post assembly to keep the counterweight inside the gate post tube. Keep the counterweight above the shipping screw until the gate post is stood upright.



Post Assembly Counterweight Figure 4




Post Assembly Counterweight Figure 5



MATERIAL HANDLING SOLUTIONS

www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209



Single VA Gate Layout Figure 6

Deaths Heatheastel		
Begin Horizontal Assembly	 Lay the gate in the proper position to allow for safe handling and efficient fit-up to the VRC. See Figure 6. 	
	2. Lay each gate post (left side and right side) with the panel guide channel facing up, and the channel open towards the middle.	
Install the Header	1. Position the gate header with the sprockets facing up and ends flush.	16615-0000-S.SMG PFL-16515-06
	2. Position the chain jump guides to leave space for the chain. See Figure 7.	Position Chain Jump Guides Figure 7
	 Bolt the chain jump guides and header to the post using four (4) 3/8-16 x 1-1/4" long bolts with lock and flat washers (weld-nut on header angle). 	ngure r
	1 Align the gets header matring ours	

4. Align the gate header, making sure the posts are square, and snug the attachment hardware.



S 7



www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209



WARNING

Entanglement hazard! Remove gloves, secure long hair, wear snugfitting clothing, and avoid wearing jewelry while working with chains.


Crush hazard! Keep hands outside and above the chain. If the lift chain does not reach the wheelblock, carefully work the lift chain around the sprocket until it does reach the wheelblock. Lift the chain from the sides. If the chain drops unaided, the weight of the chain will crush fingers. Do not allow the chain to come off the sprocket.

Header falling hazard! Loosen but do not remove the bolts when adjusting the chain jump guide or the headers. Once assembled, the header can fall if the bolts are completely removed.


NOTE The chains must be equal in length on both sides of the sprocket to align the position of the counterweight. If the chains are not equal, work the chain on the front side of the sprockets.

Install the Chains

- 1. Make sure to eliminate any chain twist. The chain should be straight between the counterweight tab and the sprocket.
- 2. Remove the #2050 master links from the end of the #35 chain on each post.
- 3. Place the center link on top of the sprocket. See Figure 8.
- 4. Thread the chain over the sprocket on the header.
- 5. Pull the chain tight over the sprocket to remove the slack in the chain without moving the counterweight.
- 6. Re-attach the #2050 master links to the #35 chain and remove the string.
- 7. Verify that the chains on each end of the gate are equal in length from the sprocket to the panel.
- 8. Loosen the header/post hardware to allow the chain jump guide to slide down into position. Do not loosen the hardware to the point that the header falls off. See Figure 9.
- 9. Set the space between the chain jump guides approximately +/- 1/8" (3mm) from the top of the chain.
- 10. Securely attach the chain jump guide.



Position Center of Chain Figure 8



Attach Chain Jump Guides Figure 9




MATERIAL HANDLING SOLUTIONS


www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209

Assemble the Gate Panel


- 1. Place the gate panels face up between the guide tracks on the gate posts.
- 2. Connect the two (2) gate panels together with nuts, washers, lock washers, and bolts. See Figure 10.
- 3. Attach the strut channel to the bottom of the gate panels. See Figure 11.
- 4. Verify that the reversing edge is attached to the bottom of the strut channel and that the lead end is on the right side.
- 5. Insert the guide blocks and attach to the gate panel and guide track. See Figure 12 and Figure 13.




Connect the two Gate Panels Figure 10



Attach Strut to Gate Panels Figure 11



Attach Guide Blocks to Gate Panel Figure 12



Attach Guide Blocks to Guide Track Figure 13



M MATERIAL HANDLING SOLUTIONS


www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209

Attach the Gate Panel to the Gate Chains

- 1. Slide the gate panel toward the header. It should move without binding on the guide tracks.
- 2. Connect the #2050 master link to the gate panel. See Figure 14 and Figure 15.
- 3. Verify that the chain length is equal on each side.
- 4. Slide the gate panel to the bottom of the gate posts.



Connect Master Link Figure 14



Connect Master Link Figure 15



MATERIAL HANDLING SOLUTIONS

www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209

Raise and Secure the Gate



Align the Gate Assembly

Anchor the Gate Post Base Plates

1. Place a strap around the gate posts to secure and maintain the assembly in place. See Figure 16.


A DANGER

Falling gate hazard! Do not lift the VA gate assembly by the header shaft or by a single strap at the center of the header.

- 2. Place two (2) straps around the header, one near each gate post. Avoid the brackets at the top of each post. See Figure 16.
- 3. To avoid sudden panel and counterweight movement, slowly raise and secure the gate assembly into place.
- 4. Tie off or continue to support the gate assembly to prevent tipping or accidental movement.
- 1. Align the center of the gate to the center of the carriage with the front side of the gate panel facing out.
- 2. Align the back side of the gate panel on the parallel chalk line.
- Drill and anchor the gate post base plates to the floor with 3/8" anchors, 3-1/2" (89mm) long.

A DANGER

Falling gate hazard! The anchor hole depth should always be deeper than the length of the anchor bolt. The recommended wedge anchor size is 3/8" diameter by 3-1/2" (89mm) long.



Secure and Lift Gate Assembly Figure 16




MATERIAL HANDLING SOLUTIONS

www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209

Plumb and Square the Gate	 Plumb and square the gate posts using a plumb bob or a level that is 4' (1,22 m) or longer. See Figure 17. Measure from the gate post to the Vertical Reciprocating Conveyor (VRC) column. 	
Install the Support Braces	1. Cut two (2) 1-1/2" x 1-1/2" (38mm x 38mm) steel angle support braces and weld to each gate post and to the VRC columns or wall. See Figure 18.	Plumb the Gate Figure 17
	2. Tighten all bolts.	
	3. Confirm that the gate is plumb and square.	
	4. Weld the gate header to the gate posts. See Figure 19.	
	5. Remove all straps on the gate.	
	Slowly slide the panel down until the chains are tight and the counterweights are off the shipping screws.	
	7 Domorrothe counterroicht	PFL-16515-15690-05A

7. Remove the counterweight shipping screw.

Weld Support Braces Figure 18



Weld Gate Header to Gate Posts Figure 19



www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209






The gate panel must float freely within the guide track or the panel interlock will not operate safely. Make sure the gate is fit properly.

Guide block fit up is important for the gate panel to operate properly and safely. This over-rides any other horizontal alignment dimensions.

- 1. Snug the gate panel and slide the blocks on one side of the channel guides.
- Set a +/- 1/8" (3mm) gap between the opposite side guide block and the gate panel. Align the gate post or trim the guide blocks if necessary. The guide block must stay trapped in the guide track. See Figure 20.



Guide Block Gap Figure 20

- 3. Make sure the gate header is level horizontally and that the gate posts are plumb and square in both directions. Shim and / or adjust as necessary.
- 4. Verify that the panel travels up and down evenly and is not binding on the guide tracks.
- 5. Adjust the bumpers as necessary.
- 6. Adjust the post spacing or panel slide blocks as necessary.
- 7. Secure and brace the gate posts to the enclosure panels, the building structure, or the VRC columns as required.
- 8. Verify that the gate panel moves freely during travel from the top to the bottom of the posts.
- 9. Verify that the gate panel clears the fully open height. If the counterweight bottoms out in the gate post before the gate panel is fully open, remove chain links to shorten the chain length.
- 10. Lift the gate panel approximately 2' (610mm) off the floor to verify that the gate panel is properly counterbalanced with panel accessories (e.g., cams, interlock flats) on the panel. The gate panel should remain in this position.
 - If the gate continues to rise, add steel bar stock to the inside bottom center of the gate panel frame.
 - If the gate drops, contact PFlow Industries, Inc. Customer Support Department for instructions.

11. Verify that the counterweight is not hitting the post base plate.



MATERIAL HANDLING SOLUTIONS

www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209

NOTE	Refer to the gate drawings to verify the placement dimensions.	2
Install the Photo Eye and Reflector	1. Attach photo eye bracket to the gate post. See Figure 21.	
	2. Attach the photo eye reflector bracket to the opposite gate post.	
	3. Verify that the photo eye and reflector are aligned with each other.	1. Photo Eye 2. Gate Closed Switch
Install the Gate Closed Switch	Attach the gate closed switch. See Figure 21.	Attach Photo Eye and Gate Closed Switch Figure 21
Install the Gate Panel Interlock	1. Position the gate interlock assembly on the inside of the gate post.	
	2. Attach the gate interlock assembly to the gate post unistrut with bolts, lock washers, and twirl nuts. See Figure 22.	
	3. Attach the actuator on the gate unistrut with bolts, lock washers, and twirl nuts. See Figure 22.	1 2. Actuator

NOTE Actuator and limit switch need to be positioned so that the actuator does not hit the limit switch.





Figure 22






MATERIAL HANDLING SOLUTIONS


www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209

Attach the Cams	Attach the three (3) cams to the gate using nuts, washers, lock washers, and channel twirl nuts. See Figure 23.
Attach the Switches	1. Attach the gate open switch. See Figure 24.
	2. Attach the down overtravel switch. See Figure 25.
	3. Attach the overtravel switch.
Install the Junction Boxes	 Install the traveling junction box using nuts, washers, lock washers, and nuts. See Figure 26.
	2. Install the stationary junction box.
	3. Attach the electric lead from the reversing edge to traveling junction box.
	4. Attach the electric lead from the


- stationary junction box to the traveling junction box.
- 5. Wire the gate per the PFlow Industries, Inc. wiring schematic.




Attach Cams Figure 23




Open Gate Switch Figure 24



Attach Overtravel Switches Figure 25



Traveling Junction Box Figure 26





Verify the Gate Operation	When power is applied to the gate:
	1. Verify that the gate panel moves up and down smoothly.
	 Verify that the gate panel opens when the carriage is present and does not open when the carriage is not present.
	3. Verify that the gate panel remains locked when the carriage leaves the floor level.
	 Verify that the gate reverses when the photo eye is obstructed.
	5. Verify that the cam on the carriage engages the actuator on the gate.
	6. With another set of eyes at the upper level, raise the gate into the overtravel limit switch to ensure the switch engages properly. Lower the gate to the undertravel switch to ensure it engages properly. Adjust the limit switch positions as needed.



www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209

Establish Placement

Make sure the placement of the gate has been established. Follow instructions beginning on page 2.

Prepare the Chains in the Gate Posts

Make sure the chains and counterweights are prepared before raising the gate posts. Follow instructions beginning page 3.



Raise and Secure the Gate Posts




Lifting hazard! Components and accessories are heavy. To prevent serious personal injury, use the appropriate lifting apparatus, tie offs, or help when moving, lifting or assembling the components or accessories.

1. Raise, position, and secure one gate post with the back face of the gate post on the parallel chalk line. Make sure the channel on the gate post is facing out and the opening of the channel is facing in. See Figure 27.

A DANGER

Falling gate hazard! The anchor hole depth should always be deeper than the length of the anchor bolt. The recommended wedge anchor size is 3/8" diameter by 3-1/2" (89mm) long.

- Drill and anchor the gate post base plate to the floor with 3/8" anchors, 3-1/2" (89mm) long.
- 3. Temporarily brace the gate post to the Vertical Reciprocating Conveyor (VRC) column or wall. See Figure 28.
- 4. Raise, position, and secure the other gate post with the back face of the gate post on the parallel chalk line. Make sure the channel on the gate post is facing out and the opening of the channel is facing in.
- 5. Temporarily brace the second gate post to the VRC column or wall. See Figure 28. *Do not anchor this post at this time.*



Channel Position Figure 27



Temporarily Brace Gate Post Figure 28



www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209



WARNING




Entanglement hazard! Remove gloves, secure long hair, wear snugfitting clothing, and avoid wearing jewelry while working with chains.


Crush hazard! Keep hands outside and above the chain. If the lift chain does not reach the wheelblock, carefully work the lift chain around the sprocket until it does reach the wheelblock. Lift the chain from the sides. If the chain drops unaided, the weight of the chain will crush fingers. Do not allow the chain to come off the sprocket.

Header falling hazard! Loosen but do not remove the bolts when adjusting the chain jump guide or the headers. Once assembled, the header can fall if the bolts are completely removed.

Install the Header 1. Position the gate header with the sprockets facing out and with the ends flush. See Figure 29. 2. Position the chain jump guides to leave space for the chain. See Figure 30. 3. Bolt the chain jump guides and gate header to the gate post using four (4) 3/8-16 x 1-1/4" long bolts with lock and flat washers (weld-nut on header angle). 4. Align the gate header, making sure the gate posts are square, and snug the attachment hardware. NOTE Install the The chains must be equal in length on both Chains sides of the sprocket to align the position of the counterweight. If the chains are not equal, work the chain on the front side of the sprockets. 1. Make sure to eliminate any chain twist. The chain should be straight between the counterweight tab and the sprocket. 2. Remove the #2050 master links from the end of the #35 chain on each post. 3. Place the center link on top of the sprocket.



Position Chain Jump Guides Figure 29



Position Chain Jump Guides Figure 30



MATERIAL HANDLING SOLUTIONS

www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209


Install the Chains (continued)	 4. Thread the chain over the sprockets on the header. See Figure 31. 5. Pull the chain tight over the sprocket to remove the slack in the chain without moving the counterweight. 6. Re-attach the #2050 master links to the #35 chain and remove the strings. 7. Verify that the chains on each end of the gate are equal in length from the sprocket to the panel. 8. Loosen the header/post hardware to allow the chain jump guide to slide down into position. Do not loosen the hardware to the point that the header falls off. See Figure 32. 	Image: constrained stateImage: constra
	9. Set the space between the chain jump guides approximately +/- 1/8" (3mm) from the top of the chain.	
	10.Securely attach the chain jump guide.	
	11. Remove the counterweight shipping screw.	
	12. Carefully pull the chain up high enough to have the counterweight above the shipping screw.	
	13.Re-install the counterweight shipping screw.	7 63 16515-0000-S SMG PFL-16515-02
		Attach Chain Jump Guides


Attach Chain Jump Guides Figure 32




MATERIAL HANDLING SOLUTIONS

Assemble the Gate Panel	 Place the gate panels between the guide tracks on the gate posts, with the smooth side of the gate facing the aisle. Connect the two (2) gate panels together with nuts, washers, lock washers, and bolts. See Figure 33. 	
	3. Attach the strut channel to the bottom of the gate panels. See Figure 34.	
	 Verify that the reversing edge is attached to the bottom of the strut channel and that the lead end is on the right side. 	Connect the two Gate Panels
	5. Insert the guide blocks and attach to the gate panel and guide track. See Figure 35 and Figure 36.	Figure 33





Attach Guide Blocks to Gate Panel Figure 35




Attach Guide Blocks to Guide Track Figure 36



MATERIAL HANDLING SOLUTIONS

Attach the Gate Panel to the Gate Chains	1. Use an appropriate lifting device to carefully slide the gate panel up towards the gate header. See Figure 37.	
NOTE	The gate panel should move up without binding on the guide tracks.	
	2. Continue to support the gate panel and attach the gate panel to the chains.	
	3. Connect the #2050 master links to the gate panel and remove the string.	
	4. Verify the chain length is equal on each side.	16515-15690.SMG PFL-16515-15690-07
Install the Support Braces	1. Measure from the gate post to the Vertical Reciprocating Conveyor (VRC) column.	Lift Gate Panel Figure 37
	 Cut two (2) 1-1/2" x 1-1/2" (38mm x 38mm) steel angle support braces and weld to each gate post and to the VRC columns or wall. See Figure 38. 	
	3. Confirm that the gate is plumb and square.	
	4. Tighten all bolts.	
	5. Weld the gate header to the gate posts. See Figure 39.	
	6. Slowly slide the panel down until the chains are tight and the counterweights are off the shipping screws.	6515-15690.0SA
	 Remove the counterweight shipping screw. 	Weld Support Braces Figure 38



Weld Gate Header to Gate Posts Figure 39



MATERIAL HANDLING SOLUTIONS

www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209




Adjust the Gate Panel



The gate panel must float freely within the guide track or the panel interlock will not operate safely. Make sure the gate is fit properly.

Guide block fit up is important for the gate panel to operate properly and safely. This over-rides any other horizontal alignment dimensions.

1. Snug the gate panel and slide the blocks on one side of the channel guides.



Guide Block Gap Figure 40

- Set a +/- 1/8" (3mm) gap between the opposite side guide block and the gate panel. Align the gate post or trim the guide blocks if necessary. The guide block must stay trapped in the guide track. See Figure 40.
- 3. Make sure the gate header is level horizontally and that the gate posts are plumb and square in both directions. Shim and / or adjust as necessary.
- 4. Verify that the panel travels up and down evenly and is not binding on the guide tracks.
- 5. Adjust the bumpers as necessary.
- 6. Adjust the post spacing or panel slide blocks as necessary.
- 7. Secure and brace the gate posts to the building structure or the VRC columns as required.
- 8. Verify that the gate panel moves freely during travel from the top to the bottom of the posts.
- 9. Verify that the gate panel clears the fully open height. If the counterweight bottoms out in the gate post before the gate panel is fully open, remove chain links to shorten the chain length.
- 10. Lift the gate panel approximately 2' (610mm) off the floor to verify that the gate panel is properly counterbalanced with panel accessories (e.g., cams, interlock flats) on the panel. The gate panel should remain in this position.
 - If the gate continues to rise, add steel bar stock to the inside bottom center of the gate panel frame.
 - If the gate drops, contact PFlow Industries, Inc. Customer Support Department for instructions.
- 11. Verify that the counterweight is not hitting the post base plate.




MATERIAL HANDLING SOLUTIONS

www.pflow.com P 414 352 9000 F 414 352 9002 6720 N. Teutonia Ave. Milwaukee, WI 53209

NOTE	Refer to the gate drawings to verify the placement dimensions.	2
Install the Photo Eye and Reflector	1. Attach photo eye bracket to the gate post. See Figure 41.	
	2. Attach the photo eye reflector bracket to the opposite gate post.	
	3. Verify that the photo eye and reflector are aligned with each other.	1. Photo Eye 2. Gate Closed Switch
Install the Gate Closed Switch	Attach the gate closed switch. See Figure 41.	Attach Photo Eye and Gate Closed Switch Figure 41
Install the Gate Panel Interlock	1. Position the gate interlock assembly on the inside of the gate post.	
	2. Attach the gate interlock assembly to the gate post unistrut with bolts, lock washers, and twirl nuts. See Figure 42.	Diversion of the second
	3. Attach the actuator on the gate unistrut with bolts, lock washers, and twirl nuts.	1 2. Actuator
NATE	Actuator and limit switch need to be positioned	

NOTE Actuator and limit switch need to be positioned so that the actuator does not hit the limit switch.









Attach the Cams	Attach the three (3) cams to the gate using nuts, washers, lock washers, and channel twirl nuts. See Figure 43.	
Attach the Switches	1. Attach the gate open switch. See Figure 44.	
	2. Attach the down overtravel switch. See Figure 45.	
	3. Attach the overtravel switch.	_
Install the Junction Boxes	 Install the traveling junction box using nuts, washers, lock washers, and nuts. See Figure 46. 	
	2. Install the stationary junction box.	
	3. Attach the electric lead from the reversing edge to traveling junction box.	
	4. Attach the electric lead from the	


- 4. Attach the electric lead from the stationary junction box to the traveling junction box.
- 5. Wire the gate per the PFlow Industries, Inc. wiring schematic.




Attach Cams Figure 43



Open Gate Switch Figure 44



Attach Overtravel Switches Figure 45



Traveling Junction Box Figure 46



MATERIAL HANDLING SOLUTIONS

Verify the Gate Operation	When power is applied to the gate:
	1. Verify that the gate panel moves up and down smoothly.
	 Verify that the gate panel opens when the carriage is present and does not open when the carriage is not present.
	3. Verify that the gate panel remains locked when the carriage leaves the floor level.
	4. Verify that the gate reverses when the photo eye is obstructed.
	5. Verify that the cam on the carriage engages the actuator on the gate.
	6. With another set of eyes at the upper level, raise the gate into the overtravel limit switch to ensure the switch engages properly. Lower the gate to the undertravel switch to ensure it engages properly. Adjust the limit switch positions as needed.